

Thermo Scientific Model 450i Hydrogen Sulfide & Sulfur Dioxide Analyzer

Pulsed fluorescence gas analyzer



The Thermo Scientific™ Model 450i Hydrogen Sulfide and Sulfur Dioxide Analyzer utilizes pulsed fluorescence technology.

- Pulsed excitation and intensity stabilization
- Reflective bandpass filters
- Temperature stabilization reaction chamber
- Stable, long-life UV source
- Superior zero stability



The Thermo Scientific Model 450i analyzer operates on the principle that H₂S can be converted to SO₂. As the SO₂ molecules absorb ultraviolet (UV) light and become excited at one wavelength, the molecules then decay to a lower energy state emitting UV light at a different wavelength.

Specifically,



The pulsing of the UV source lamp serves to increase the optical intensity whereby a greater UV energy throughput and lower detectable SO₂ concentration are realized.

Reflective bandpass filters, as compared to commonly used transmission filters, are less subject to photochemical degradation and are more selective in wavelength isolation. This results in both increased detection specificity and long term stability.

This state-of-the-art gas analyzer also offers features such as an ethernet port as well as flash memory for increased data storage.

Ethernet connectivity provides efficient remote access, allowing the user to download measurement information directly from the instrument without having to be on-site.

You can easily program short cut-keys to allow you to jump directly to frequently accessed functions, menus or screens. The larger interface screen can display up to five lines of measurement information while primary screen remains visible.



Thermo Scientific Model 450i Hydrogen Sulfide & Sulfur Dioxide Analyzer

Thermo Scientific Model 450i Hydrogen Sulfide and Sulfur Dioxide Analyzer

Preset Ranges	0-0.05, 0.1, 0.2, 0.5, 1, 2, 5, and 10 ppm, 0-0.2, 0.5, 1, 2, 5, 10, 20, and 25 mg/m ³		
Extended Ranges	0-0.5, 1, 2, 5, 10, 20, 50 and 100 ppm, 0-2, 5, 10, 20, 50, 100, 200, and 250 mg/m ³		
Custom Ranges	0-0.05 to 100 ppm, 0-0.2 to 250 mg/m ³		
Zero Noise	1.0 ppb (Manual SO ₂ or Combine Sulfur)	3.0 ppb (Automatic mode SO ₂ or H ₂ S)	(10 second averaging time)
	0.5 ppb	1.5 ppb	(60 second averaging time)
	0.25 ppb	0.75 ppb	(300 second averaging time)
Lower Detectable Limit	2.0 ppb (Manual SO ₂ or Combine Sulfur)	6.0 ppb (Automatic mode SO ₂ or H ₂ S)	(10 second averaging time)
	1.0 ppb	2.0 ppb	(60 second averaging time)
	0.5 ppb	1.5 ppb	(300 second averaging time)
Zero Drift (24 hour)	Less than 1 ppb		
Span Drift (24 hour)	+/-1% Full Scale		
Response Time	80 seconds (10 second average time)		
	110 seconds (60 second average time)		
	320 seconds (300 second average time)		
Precision	1% of reading or 1 ppb (whichever is greater)		
Linearity	+/-1% full scale < 100 ppm		
Sample Flow Rate	1.0 liter/min.		
Converter Efficiency	> 80% H ₂ S to SO ₂ . (Note: Various other Sulfur compounds can be converted at varying %)		
Operating Temperature	20°C to 30°C		
Power Requirements	100 VAC, 115 VAC, 220-240 VAC +/-10% @ 300W		
Size and Weight	16.75"(W) x 8.62"(H) x 23"(D), 48 lbs. (21.8 kg)		
Outputs	Selectable Voltage, RS232/RS485, TCP/IP, 10 Status Relays, and Power Fail Indication (standard). 0-20 or 4-20 mA Isolated Current Output (optional)		
Inputs	16 Digital Inputs (standard), 8 0-10 Vdc Analog Inputs (optional)		
Available Options	Teflon particulate filter, Rack mounts, Rear extenders		

Ordering Information

Model 450i H₂S/SO₂ Analyzer

Choose from the following configurations/options to customize your own Model 450i analyzer

1. Voltage options:

A = 115 Vac 50/60 Hz

B = 220 Vac 50/60 Hz

J = 100 Vac 50/60 Hz

2. Internal zero /span:

N = No zero / span assembly

Z = Internal zero / span assembly

P = Internal permeation span source with zero/span assembly

3. Sample Handling:

S = Standard

E = External Converter Setup

(no converter supplied)

H = Selective SO₂ Scrubber

(Continuous H₂S Analysis only)

4. Optional I/O:

A = No optional I/O (standard)

C = 0-20, 4-20mA current output -

6 channels, 0-10v analog input - 8 channels

5. Mounting hardware:

A = Bench mounting and Ears/Handles, EIA

Your Order Code: 450i - _ _ _ _ _

To maintain optimal product performance, you need immediate access to experts worldwide, as well as priority status when your air quality equipment needs repair or replacement. We offer comprehensive, flexible support solutions for all phases of the product life cycle. Through predictable, fixed-cost pricing, our services help protect the return on investment and total cost of ownership of your Thermo Scientific products.

For more information, visit our website at thermoscientific.com

© 2014 Thermo Fisher Scientific Inc. All rights reserved. All trademarks are the property of Thermo Fisher Scientific Inc. and its subsidiaries. Specifications, terms and pricing are subject to change. Not all products are available in all countries. Please consult your local sales representative for details.

This product is manufactured in a plant whose quality management system is ISO 9001 certified.

USA

27 Forge Parkway
Franklin, MA 02038
Ph: (866) 282-0430
Fax: (508) 520-1460
customerservice.aq@thermofisher.com

India

C/327, TTC Industrial Area
MIDC Pawane
New Mumbai 400 705, India
Ph: +91 22 4157 8800
india@thermofisher.com

China

+Units 702-715, 7th Floor
Tower West, Yonghe
Beijing, China 100007
+86 10 84193588
info.eid.china@thermofisher.com

Europe

Takkebijsters 1
Breda Netherlands 4801EB
+31 765795641
info.aq.breda@thermofisher.com

Thermo
SCIENTIFIC

A Thermo Fisher Scientific Brand